

JAMES BAROUD

EN USER GUIDE

FR Guide de L'utilisateur

DE Benutzerhandbuch

ES Guía del usuario

PT Guia de utilizador

▲ IMPORTANT

EN When closing the tent fold the bedclothes in the corners and do not place any object under the arms of the mechanisms.

FR Avant de fermer la tente plier le linge de lit dans les coins et ne placez aucun objet sous les bras des mécanismes.

DE Beim Schließen des Zeltes klappen Sie die Bettwäsche zusammen in den Ecken und legen Sie keine Gegenstände unter die Arme der Mechanismen.

ES Antes de cerrar la tienda doblar la ropa de cama en las esquinas y no coloque objetos bajo los brazos de los mecanismos.

PT Antes de fechar a tenda, dobrar a roupa de cama nos cantos e não colocar objetos debaixo dos braços dos mecanismos.



JAMES BAROUD WARRANTY



5 YEARS WARRANTY - It includes the ABS, the mechanism, the canvas, the lift supports, the ladder and its fixings, the zippers, the mosquito net, the mattress, the rail and fixings, the headliner of the upper shell.



2 YEARS WARRANTY - It includes the color, the extractor, the flashlight, the tent locks.

In case of request of warranty support, the invoice will be requested, and photos or a film about the problem should be sent to: warranty@jamesbaroud.com. In warranty claims the tent should be packed in the original box to be transported. In the case of litigation or contestation the court of Porto, Portugal have jurisdiction.

READ MORE ON



jamesbaroud.com

@jamesbaroudofficial





Odyssey

OPEN





1

CLOSE





6

CLOSE





5

OPEN





2

OPEN



3

CLOSE



4

 **JAMES BAROUD**


EN INSTALLATION GUIDE

FR Guide d'installation

DE Installationsanleitung




ES Guía de instalación

PT Guia de instalação








Clamps

PLACEMENT OF CLAMPS AND ROOF BARS



- FR Placement des pattes fixation et barres de toit
- DE Platzierung der Klammern und bars
- ES Colocación de puente de fijación y barras de techo
- PT Colocação de grampos e barras




EN Position and distribution of the roof racks

FR Positionnement et la distribution des barres de toit

DE Positionierung und den Vertrieh von Dachtrager

ES Posición y distribución de las barras de techo

PT Posição e distribuição das barras de teto




EN With 2 Bars

FR Avec 2 barres

DE Mit 2 Bars

ES Con 2 barras

PT Com 3 barras




EN With 3 Bars

FR Avec 3 barres

DE Mit 3 Bars

ES Con 3 barras

PT Com 3 barras



EN With 4 Bars

FR Avec 4 barres

DE Mit 4 Bars

ES Con 4 barras

PT Com 4 barras



EN Minimum weight supported by bar should be 45kg

FR Poids minimum supporté par barre devrait être 45kg

DE Mindestgewicht von 45k unterstützt wird, sollte sein

ES Peso mínimo soportado por barra deberá ser 45 kg

PT Peso mínimo suportado por barra deverá ser 45kg

jamesbaroud.com



@jamesbaroudofficial

✉ contact@jamesbaroud.com

