

SPIRIT




NL GASBARBECUE Montageleidraad

220 ORIGINAL

LP/NG









VEREIST GEREEDSCHAP:



7/16"



7/16", 9/16"




x2


54706

NL
09/26/18


1



1




1




1




1




1




1




1




1



1



1



1



1




2



1



2



2



1



2



1



1




- 8



- 2

1



- 29




- 25




- 2

1



3




- 2




- 2



1



1




- 2




- 2

1




- 2

1



- 8



- 4


2



- 2



- 1




- 2

1





1

N




2

N




3

N




4


B




5 **B**  - 6  - 6




7 **B**  - 4  - 4





6 **B**  - 4  - 4




8 **B**  - 2  - 2




9





10




11



12




13





Zie de gebruikershandleiding voor de volledige gasinstructies.


14





15



16




17




Draai de moeren handvast. Draai ze vervolgens nog een kwartslag. NIET TE STRAK VASTDRAAIEN.




18



19





20




Zie de gebruikshandleiding voor het bedradingsschema van de ontstekingsmodule.


21






22





23




24




25




26



27



28



29





WEBER-STEPHEN PRODUCTS LLC
www.weber.com